



**1 + on BRE250**

**2 + Bosch motor**

**3 + main battery (Bosch)**

**4 Gnd BRE250**

**5 Gnd main battery (Bosch)**

**6 Gnd motor Bosch**

### How to connect

Cut the + motor wire and connect it to (2) + motor PCB

Cut the + main battery (Bosch) and connect it to 3 on PCB

Connect the + on BRE250 with 1 on PCB

Cut the - motor wire and connect it to (6) - motor PCB

Cut the - main battery (Bosch) and connect it to 5 on PCB

Connect the - on BRE250 to 4 on PCB